

# **HANGING INSTRUCTIONS**

**S**

Used for the Cane references (CEA1..) of the Cane & Sand collection

## **RECEPTION OF THE MATERIAL**

Be sure all material has the same run lot number before installation. Final inspection should be made as to correct pattern, colour and any defects in craftsmanship. No claims will be accepted beyond the installation of 3 strips. Absolutely no labour claims will be considered. Application of material is interpreted as acceptance of material and conditions of installation.

Due to the natural products used, and the partially hand-made production, irregularities appear in the structure and colour of the wallcovering. These irregularities may appear from one roll to another, but even within one and the same roll. It can therefore be recommended to compare and match the different strips before the installation.

## **WALLCOVERING – INSTALLATION**

### **1. Wall preparation**

Ensure surfaces are clean, smooth, dry, firm and uniformly coloured. Do not hang over glossy or non-porous places, stains. Painted walls should be washed down with Tri Sodium Phosphate to remove grease or soil. Glossy paint should be dulled by sandpaper. Never hang over new plaster or unprimed wall areas. For wallboard, ply or drywall, fill all cracks and prepare the surface with an acrylic basecoat.

### **2. Preparation of the strips**

- Measure and cut the strips. Add 2" to 4" (5 to 10 cm) to top and bottom of each strip.
- Match the different strips, number them at the back, and hang them in the same sequence.
- Reverse alternate lengths when instructed to do so by label on the roll.

### **3. Installation**

**Abundantly humidify the back of the wallcovering and let it soak for 20 minutes.**

Apply a ready mixed PVA or EVA clear adhesive to the wall. If the wall is blocked, use an appropriate glue. Apply regularly and sufficiently (about 7 ozs/sqyd- 200 gr/m<sup>2</sup>). Follow the instructions of the adhesive manufacturer.

Respect the open time recommended by the adhesive manufacturer (± 5 minutes), so that the glue can penetrate into the wall or evaporate.

Smoothen the wallcovering with a rubber roller, taking care to **remove all the blisters.**

## **ATTENTION**

- **Make sure the adhesive is spread out evenly over the whole surface to ensure good adhesion to the wall.**
- **Do not use too much adhesive to avoid seam tearing stains on the wallcovering.**
- **Never allow the adhesive to get on front of the material.**

# **HANGING INSTRUCTIONS**

**T**

Used for the Sand-references (SDA1..) of the Cane & Sand collection

## **RECEPTION OF THE MATERIAL**

Be sure all material has the same run lot number before installation. Final inspection should be made as to correct pattern, colour and any defects in craftsmanship. No claims will be accepted beyond the installation of 3 strips. Absolutely no labour claims will be considered. Application of material is interpreted as acceptance of material and conditions of installation.

The borders and fabrics are coordinating items. Due to different materials, processes and dye lots, we cannot guarantee a perfect colour match. Small differences in shading between different run lots or between sample and actually delivered material cannot be avoided.

## **WALLCOVERING – INSTALLATION**

### **1. Wall preparation**

Ensure surfaces are clean, smooth, dry, firm and uniformly coloured. Do not hang over glossy or non-porous places, stains. Painted walls should be washed down with Tri Sodium Phosphate to remove grease or soil. Glossy paint should be dulled by sandpaper. Never hang over new plaster or unprimed wall areas. For wallboard, ply or drywall, fill all cracks and prepare the surface with an acrylic basecoat.

### **2. Preparation of the strips**

- Measure and cut 3 strip lengths. Add 2" to 4" (5 to 10 cm) to top and bottom of each strip.
- For printed patterns, plan your match from the roll before cutting.
- Mark each strip coming from the roll on the back and hang in the same sequence.
- Reverse alternate lengths when instructed to do so by label on the roll.

### **3. Installation**

Apply a ready mixed PVA or EVA clear adhesive to the wall. Follow the instructions of the adhesive manufacturer. Do not use too much adhesive (about 7 ozs/sqyd- 200 gr/m<sup>2</sup>).

Respect the open time recommended by the adhesive manufacturer to penetrate into the wall or to evaporate.

## **ATTENTION**

- **Make sure the adhesive is spread out evenly over the whole surface to ensure good adhesion to the wall. This will avoid open seams.**
- **Do not use too much adhesive to avoid seam tearing stains on the wallcovering.**
- **Never allow the adhesive to get on front of the material.**