

HANGING INSTRUCTIONS

T

For all HEA.. references

RECEPTION OF THE MATERIAL

Be sure all material has the same run lot number before installation. Final inspection should be made as to correct pattern, colour and any defects in craftsmanship. No claims will be accepted beyond the installation of 3 strips. Absolutely no labour claims will be considered. Application of material is interpreted as acceptance of material and conditions of installation.

The borders and fabrics are coordinating items. Due to different materials, processes and dye lots, we cannot guarantee a perfect colour match. Small differences in shading between different run lots or between sample and actually delivered material cannot be avoided.

WALLCOVERING – INSTALLATION

1. Wall preparation

Ensure surfaces are clean, smooth, dry, firm and uniformly coloured. Do not hang over glossy or non-porous places, stains. Painted walls should be washed down with Tri Sodium Phosphate to remove grease or soil. Glossy paint should be dulled by sandpaper. Never hang over new plaster or unprimed wall areas. For wallboard, ply or drywall, fill all cracks and prepare the surface with an acrylic basecoat.

2. Preparation of the strips

- Measure and cut 3 strip lengths. Add 2” to 4” (5 to 10 cm) to top and bottom of each strip.
- For printed patterns, plan your match from the roll before cutting.
- Mark each strip coming from the roll on the back and hang in the same sequence.
- Reverse alternate lengths when instructed to do so by label on the roll.

3. Installation

Apply a ready mixed PVA or EVA clear adhesive to the wall. Follow the instructions of the adhesive manufacturer. Do not use too much adhesive (about 7 ozs/sqyd- 200 gr/m²). Respect the open time recommended by the adhesive manufacturer to penetrate into the wall or to evaporate.

BORDER INSTALLATION

1. Surface preparation

We advise to first install the wallcovering. Preferably, install the border when the underlying wallcovering has dried. This drying time will depend upon the ambient temperature and humidity.

2. Border preparation

Use a special border adhesive for non-absorbent surfaces. Apply the adhesive to the backing of the border. NO SOAKING REQUIRED.

ATTENTION

- **Make sure the adhesive is spread out evenly over the whole surface to ensure good adhesion to the wall. This will avoid open seams.**
- **Do not use too much adhesive to avoid seam tearing stains on the wallcovering.**
- **Never allow the adhesive to get on front of the material.**

HANGING INSTRUCTIONS

B

For references HEA2..

The wallcovering can be installed horizontally or vertically.

For a horizontal hanging, first draw a vertical line with the help of a plump line. Then measure from the ceiling a distance which is 5 cm (2 inches) shorter than the width of the wallcovering and mark that place. With a set square, draw a horizontal line, which will serve as a guideline during the hanging.